

NOTE:
BOTTOM LAYER OF INSULATION SHALL BE LAID DOWN IN
A STAGGERED PROFILE. STAGGER AND OFFSET TOP LAYER
OF INSULATION FROM BOTTOM LAYER TO PREVENT
ALIGNED EDGES.

